

SLATWALL ACOUSTIC PANELS



Fitting Guide

NATUREWALL



Transforming your room has never been easier. Create your dream wall with SlatWall in hours, not days, by following these simple steps.

What You'll Need

- SlatWall Panels (Full Height or Half-Height)
- 16 (3.5 x 35mm) screws per full height panel
OR Grab Adhesive and Sealant Gun
- Tape measure
- Spirit level

You May Also Need

- Pencil
- Square tool
- Fine-toothed hand saw
- Sharp utility knife
- Masking tape
- Jigsaw or Circular Saw
- 120-grit sandpaper
- Screwdriver

PROCESS

Plan Ahead

1. If storing the panels before installation, keep them laid flat to minimise bowing.
2. Remove any screws, nails or other fixtures from your wall.
3. Make sure your wall is clean, smooth and level. If your wall is uneven, fill any holes or sand down high spots to create a smooth surface.

Top tip: We recommend noting the placement of cables and concealed pipework to avoid them during installation.

4. Unbox all your packages and check the panels before installation.
5. Decide on your layout, considering whether you are using Full Height or Half-Height panels to suit your space.
6. Cut the panels to size if needed (see next step).

Make The Cut

1. Measure and mark where you need to cut.

Top tip: For Full Height panels, ensure your measurements are accurate to avoid wastage. Half-Height panels may require fewer cuts.

2. Use a square tool and pencil to draw a straight, precise cutting line.

Top tip: Place masking tape along the cut line, this will help reduce splintering and keep cut edges neat.

3. For straight cuts, use a fine-toothed hand saw for a clean edge. A jigsaw or circular saw can also be used for faster cuts, especially on larger sections; guide it steadily along the marked line to avoid chipping.
4. Lightly sand any cut edges for a smooth finish if needed. We recommend using 120-grit sandpaper.

Form a Strong Bond

We recommend doing a test-fit with your panels first, holding them up to the wall to inspect your panels and check the measurements and cuts are accurate.

With Screws

1. Install your first panel by aligning screws in rows of four and fixing it to your wall. Pick screws in a colour that coordinates with your felt backing and use the appropriate fixings for your wall (e.g. wall plugs).

Top tip: Space your rows of 4 screws evenly down the length of the panel leaving a small gap around the panel's edge.

2. For maximum acoustic performance, install the panels onto 45mm (D) battens with 45mm mineral wool between each batten.
3. Repeat for each panel.

Important: If installing the panels on a ceiling, fix the screws to structural points such as joists.

With Hybrid Grab Adhesive

1. Apply Grab Adhesive in three wavy lines along the back of your first panel, covering its full length.

Top tip: One tube of adhesive covers approx. 1 full height panel.

2. Position the 'first' panel against your wall.

Important: Ensure that when fitting the first panel use a spirit level against the panel's edge to ensure panels are straight.

3. Apply pressure all along the panel and press firmly to secure it.
4. Repeat for each panel.

Do As You See Fit

If adding fixtures and fittings, such as shelves or TV brackets, drill through the panel and sub wall, then use appropriate wall plugs and screws.

To complete the look of Half-Height SlatWall Panels, we recommend adding a matching Top Trim. For full details and fitting instructions, refer to their product pages on the Naturewall website.

NATUREWALL

Now comes the moment of truth,
it's time to step back and take in the
transformation of your beautiful wall!

If you have any questions about
installing SlatWall Acoustic Panels,
please contact our friendly customer
service team at:

info@naturewall.com
+44 (0)808 501 5592