

# Apollo Storm series assembly instructions



4 x threaded hex cap bolts

4 x black isolation discs

4 x leg tubes

4 x spikes & locknuts\*

\*Note (**locknuts required for base module only**)

1 x hex key (not shown)

## IMPORTANT

WHEN STACKING THE MODULES, BE SURE TO NOT ALLOW THE LEG SPIKES TO TOUCH THE WOOD OF THE SHELF BELOW.

1



Fit the hex cap bolt through the wood panel

2



Slide the isolation disc down the bolt making sure the protruding lip located on the inner hole is facing the wood

3



Position the black isolation disc over the stud with the inner lip facing the wood.(it does not need to be flush with the wood as it will self locate during assembly)

4



Slide the leg tub over the bolt and screw onto the threaded insert located inside the leg

5



Use the hex key to tighten.

6



The leg assembly should now look like this

spike

**LOCKNUTS FOR BASE MODULE ONLY. SHELF MODULES DO NOT REQUIRE LOCK NUTS**

7

Lock nut (base module only)



Fit spike. Stack the modules adjusting the spikes as required.

IF YOU HAVE A DELICATE FLOOR COVERING SPIKE SHOES ARE AVAILABLE AS A COST OPTION. PLEASE CONTACT YOUR DEALER FOR MORE DETAILS.



## Important:- Instructions for Stacking Storm Modules

If the spikes on the ends of each leg do not align with the bolt top holes of the shelf beneath, follow these steps:

1. **Loosen the Bolts:** Slightly loosen all four bolts on the shelf module you're attempting to place.

2. **Position the Shelf:** Carefully place the shelf onto the lower shelf, guiding each spike into its corresponding bolt hole by hand.

3. **Tighten the Bolts:** Once all spikes are securely in place and seated correctly, tighten the top bolts.

**Do not overtighten.**

**Verify Alignment:** Double-check to ensure all four leg spikes are correctly seated in the bolt holes.

By following these steps, you can ensure proper alignment and stability when stacking your Storm Modules.