
CORRIDOR® BAR 5620

INSTRUCTION MANUAL

LET'S GET STARTED.



DESIGN MATTHEW WEATHERLY



Congratulations on the purchase of your Corridor Bar 5620 from BDI. Your cabinet has been designed to provide a lifetime of enjoyment. This manual will provide you with assembly instructions and other helpful information that will ensure that you get the most out of your cabinet. Please save it for future reference.

Your Corridor bar has been engineered for simple assembly. Please follow these directions carefully to prevent any damage.

Should you need further assistance, contact BDI at customerservice@bdiusa.com.


ENJOY!





HARDWARE AND COMPONENTS

Unpack and identify the parts listed below. The assembly workspace should be a non-marring surface, such as carpet. For missing hardware pieces, please contact BDI Customer Service at customerservice@bdiusa.com. For all other concerns, please contact your BDI retailer.


Do not use power tools for the assembly of this product.
























HARDWARE AND COMPONENTS











Slide tab of (C1 & C2) Metal Legs into (C3) Crossbar and attach with 4 (H1) Screws and tighten with (T2) Hex Wrench.

PART/DESCRIPTION	ОТУ
T2-HEX WRENCH	1
H1-SCREW	4



Using 8 (H1) Screws and 1 (H2) Screw, attach base assembly to (A) Cabinet with (T2) Hex Wrench. Start all screws before fully tightening all screws.

PART/DESCRIPTION	ОТУ
T2-HEX WRENCH	1
H1-SCREW	8
H2-SCREW	1




STEP 3. INSTALL DOOR PULLS AND RUBBER BUMPER




With help from another person, carefully position (A) Cabinet upright and install (H6) Door Pulls using (H3) Screw and (T1) Phillips Screwdriver. Adhere (H5) Rubber Bumpers to the top of (A) Cabinet.

PART/DESCRIPTION	ОТУ
T1-PHILLIPS SCREWDRIVER	1
H3-SCREW	4
H5-RUBBER BUMPER	5



Place **(C4) Glass Top** onto the rubber bumpers on the **(A) Cabinet**. Be sure to place the satin etched side up.



ADJUSTABLE SHELF


The shelf pins located inside the right compartment may be repositioned using (T1) Phillips


Screwdriver, allowing you to raise or lower the Adjustable Shelf to the desired level.

I FV	/FI	$\cap \Delta$	RI	N	FΤ

Once the unit is completely assembled and in its final position, adjust the levelers using (T3) Open Mouth Wrench as necessary. If you prefer to have the doors remain in a fully-open position, partially extending the two (2) front levelers is desirable. This action will orient the cabinet back slightly, preventing the open doors from swinging towards their closed position.

PART/DESCRIPTION	ОТУ
T1-PHILLIPS SCREWDRIVER	1
T3-OPEN MOUTH WRENCH	1






ADJUSTING THE DOOR GAPS

With both doors closed, check to see if the top corners of the doors align. If not, dial out the corresponding front leveler under the door that is sagging.

EXAMPLE: If the door on the right is low, dial out the right front leveler to raise the door back into alignment with the left door.



To move the right door up, dial the front, right leveler out. To move the left door up, dial the left, front leveler out.

CARE & MAINTENANCE

Your BDI furniture has been constructed with the finest materials, carefully manufactured, and designed to last a lifetime. Regular furniture care will prolong your enjoyment and keep it looking its best. Here are some general tips for taking care of BDI furniture. Your surfaces may vary.

GLASS

Glass surfaces are maintained using household glass cleaner and a paper towel or cloth.

SATIN-ETCHED GLASS

This uniquely smooth-to-the-touch glass surface can be regularly maintained using household glass cleaner and a paper towel or cloth.

A 'Magic Eraser' removes minor scratches or scuffs not eliminated using a paper towel or cloth. 'Magic Eraser' is a melamine foam product available at any grocery store or home improvement center. Dampen the entire glass surface and the Magic Eraser, then rub the whole surface in broad, even strokes using moderate pressure. Clean and dry the surface with a paper towel. Check for results and repeat as necessary. Any scratches or scuffing not eliminated by one of the above methods can often be addressed by 'refreshing' the glass. This process should not be required more than once per 6–12 months. See this brief video for the simple method: www.bdiusa.com/glass

WOOD

Wood surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. Do not use glass cleaner on wood. If moisture remains, dry the surface with another cloth. If needed, a gentle, non-abrasive cleanser may be used, but wipe away all cleaner residue and dry the surface with a cloth.

BDI's wood finishes feature natural hardwood solids and veneers. Wood is a product of nature and—unlike man-made materials that can be manufactured to strict and consistent specifications—has natural imperfections that are part of its appeal and character. Every piece of wood differs from every other, even when coming from the very same tree. As such, grain, texture, and tone variation should be expected from one panel or piece of furniture to the next.

While BDI's stained wood finishes are stable in tone & appearance, all finishes are subject to some degree of discoloration with prolonged exposure to direct sunlight. Please avoid positioning your BDI cabinet in any area with ample direct sunlight. To learn more about the features of natural wood, visit www.bdiusa.com/wood

METAL, PORCELAIN, & PAINTED SURFACES

Surfaces should be cleaned with a slightly damp (not saturated) cloth or paper towel. If moisture remains, dry the surface with another cloth. If needed, a gentle, non-abrasive cleanser may be used, but be sure to wipe away all cleaner residue and dry the surface with a cloth.

BDI warrants to the original purchaser that for the below-stated warranty term, BDI will repair or replace any product, part, or component covered by this warranty that fails under everyday use due to a defect in material or workmanship. BDI will repair or replace the product mentioned above, part, or component with a comparable product, part, or component. The decision to repair or replace will be at BDI's sole discretion.

BDI furniture is warranted for three (3) years from the date of purchase, as shown on your sales receipt. The warranty period starts from the date of purchase. This warranty extends only to the original purchasers who acquire new products from BDI Authorized Resellers. To be eligible for warranty coverage, any product, part, or component must have been assembled, installed, used, and maintained according to BDI's published instructions. Any modification to the original product voids the warranty.

To view BDI's complete warranty information, visit www.bdiusa.com/warranty

PRODUCT REGISTRATION

Registering your new BDI product allows us to send you important product updates, service information, and helpful hints related to your BDI products.

Register today, and you will be entered to win free a BINK table from BDI: www.bdiusa.com/register





SERIOUS OR FATAL CRUSHING INJURIES CAN OCCUR FROM FURNITURE TIP-OVER. TO HELP PREVENT TIP-OVER:

- Install tip-over restraint.
- Place heaviest items in lower compartments.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.

USE OF TIP-OVER RESTRAINT MAY REDUCE—BUT NOT ELIMINATE—THE RISK OF TIP-OVER.



These distinctive product configurations are protected by US and international patents, trade dress, and/or copyright laws. Corridor & BDI are trademarks of Becker Designed, Inc. All rights reserved. ©2024, BDI | V.01.22.2024

Made in China.