


ORANGE™

O EDITION MKII HEADPHONES

MANUAL




BOX CONTENTS



HOW TO PAIR

VOICE PROMPTS

- Power on, Pairing - Connected
- Disconnected, Pairing
- Battery Full
- Battery Low, Please Charge
- ANC On
- ANC OFF
- Ambient Sound




Press and hold for 3-5 seconds for power on and the headphones will automatically go into pairing mode.

* To enter pairing mode again, power off and then hold Power Button for 5 seconds


Please connect the headset with your mobile device within 5 minutes.

FUNCTIONS



	Double press Power on/off button, call back the last call you dialed out. Press once to activate voice assistant, press it again to end voice assistant or play the audio when connected to the headphones.
	Press once for Ambient Sound Press again for ANC on.
	Press once, ANC off. Press again, ANC on.


CHARGING



To charge connect to computer or USB 5V 1A (or less) output device.


RESET

Reset headphones to the factory settings as follows:



1. Turn off the headphones, remove them from the list of paired devices and switch off bluetooth on your device.
2. Turn on the headphones so they're in pairing mode, the LED will flash red and blue.
3. Quickly press the multifunction button 5 times, resetting the headphones.
4. Switch on Bluetooth on your device.
5. The headphones will now be visible for pairing.

WIRED CONNECTION



Step 1 : Plug one end of the 3.5 mm Audio Cable to the headphones.


Step 2 : Plug the other end of the 3.5 mm Audio Cable into the Audio Output Socket of your Audio device.

When you use the 3.5mm Audio Cable to connect the headphones to a device, all functions must be completed on your device.

SPECIFICATIONS

BT Version	V5.0
Effective Distance	10m
Frequency Range	20Hz~20KHz
Sensitivity	105±3dB
Impedance	32~
Power Input	DC5V1A
Speakers	40mm Driver
Charging Time	1-3 Hours
Charging Connector	USB-C
Battery Capacity	800mAh
FCC ID	2A3TF-OEDITIONMKII

SWIPE CONTROL



BUTTON FUNCTIONS -

	Double click to play music. Double click again to pause.
	Double click to answer calls. Double click to end calls.
	Hold down to decline calls.
	Swipe left to play previous track.
	Swipe right to play next track.
	Swipe up to increase volume.
	Swipe down to turn down volume.

PLEASE READ THIS MANUAL CAREFULLY BEFORE USE.



Safety warnings

Do not place near any naked flame sources, such as lighted candles. Dispose of batteries responsibly and be aware of the environmental effects of battery disposal. Do not expose the battery (installed) to excessive heat, such as fire, etc.



Warning

To prevent possible hearing damage, do not listen at high volume levels for long periods. For your own safety, please be aware of your surroundings when using these headphones.

--- The symbol indicates DC voltage



RECYCLING


ORANGE™

O EDITION MKII HEADPHONES

APP INTRODUCTION



EQ SETTING



You can listen to your music by choosing a preset EQ or enhance your sound by customising your own EQ setting.

In order to customise your EQ setting, ANC must be turned off.

After customising your EQ Setting, remember to save it.

HOME PAGE



Editing Headset Properties

Play Control

Battery Indicator


ANC Control

Find It

EQ Setting

Touch Pad Control settings

TOUCH PAD CONTROL SETTINGS




You can customise the touch pad to your preference, such as volume operation, next/previous song or triple tap for other functions.

Game mode

In gamemode the headphones enter a low latency mode, transmission latency will be as low as 60ms.

PLAY CONTROL




Easily adjust volume, switching songs, and controlling play/pause using touch control functions.


You must be playing music/audio through your device for this function to be enabled.

ANC CONTROL

In ANC mode, you can change from ANC, Normal, Transparency, adjust noise reduction or ambient sound to suit your preference. You can also set the level of noise reduction.



FIND IT



You have the option to find your headphones using the "Find It" page.

This feature enables you to play a sound even if the volume is low. The headphones need to be within 10 meters of your device and will remember what location your headphones were used last.