


Manual V1.0

PYRAMID AMP – MANUAL

FRONT



1. Power On/Off – Volume Control

Turn the dial to switch the unit on or off. Twist the dial to control the volume.

2. Prism Indicator Light

indicated by a red pulsing glow.

REAR PANEL



1. DC Power Input Socket



Power input socket for the power adaptor (supplied)

2. Speaker Outputs Left/Right



Speaker output connections for left and right speakers. Cables supplied



3. Treble Control

Adjusts the high-end response.



4. Bass Control

Adjusts the low-end response.



5. Stereo AUX inputs (phonos)

Auxillary input for Stero Phono connection.



6. AUX input socket 3.5mm

Connect your audio device via AUX. The prism light will glow green when connected via AUX



7. Bluetooth On/Off Button

Push/depress the button to swith the Bluetooth mode on/off. Once switched on, the prism will flash blue until a bluetooth device is connected. The light will then stop flashing and glow blue continuously. To connect to Bluetooth, turn on the Bluetooth setting on your device and search for Orange Pyramid and select. The Pyramid should now be connected. If you are experiencing difficulties with your Bluetooth connection, try the Bluetooth reset button (9) located on the base of the Pyramid.

Bluetooth pairing name : Orange Pyramid

relative levels of the left and right outputs



9. Bluetooth Pairing/ Connect Button

The Bluetooth reconnection button is located on the base of the Pyramid and can be used to clear the Bluetooth connection memory allowing a device to be discoverable.

Bluetooth Pairing name : Orange Pyramid

OPERATION

Plug in the power adaptor to the power socket (rear 1) and click/Turn Vol control (front 2) clockwise to switch on Pyramid. Once switched on, the prism (front 1) will glow Green and is ready for use via the stereo phono inputs (rear 5) or the 3.5mm auxillary input(rear 6). To use the Bluetooth mode, depress button (rear 7) and the prism will now flash Blue until a BT device is detected (Bluetooth pairing name : Orange Pyramid) once connected the Prism will glow Blue contiuously. Adjust the Treble and Bass via the control knobs on the rear (3 & 4) to suit.

PYRAMID AMP – SPEC TABLE

Features:

Bluetooth enabled amplifier with Stero phon inputs
and 3.5mm auxillary input.

	the base of the unit.
Front Panel	Power on/Volume control
Rear Panel	Bluetooth on/off, Bass and Treble controls, Auxillary input (3.5mm), Stereo Phono inputs, Speaker output terminals, Power input socket
Output Power:	• Output Power : RMS 40W x 2 4ohm (Class D amplifiers)
Unboxed Dimensions (W x H x D):	162 X 107 X 162 mm
Unboxed Weight:	746g
D.C Input:	19.5Vdc 5A (from dedicated power supply)
Power Supply Mains Input Voltage:	100-240V
Finish Options:	White



HELP WITH MY GEAR

Contact us

Register Gear

Gear Manuals

SISTER WEBSITES

Orange Essentials

Orange Learn